

## Чорнило BTD60BK BARVA

для Brother



Brother DCP-T220, T225, T300, T310, T420W, T425W, T500W, T510W, T520W, T700W, T710W, T720W, T820W; MFC-T800W, MFC-T810W, MFC-T910DW, MFC-T4500W, HL-T4000DW



Brother BTD60BK, BT6000BK

	100 мл	180 мл	1 л
Black	BBTD60-743	BBTD60-753	BBTD60-757
BK/C/M/Y	BBTD60-100-MP		

## Чорнило BT5000C/M/Y BARVA для Brother



Brother DCP-T220, T225, T300, T310, T420W, T425W, T500W, T510W, T520W, T700W, T710W, T720W, T820W; MFC-T800W, MFC-T810W, MFC-T910DW, MFC-T4500W, HL-T4000DW

Yellow

Водорозчинне



	100 мл	180 мл	1л
Cyan	BBT5000C-744	BBT5000C-754	BBT5000C-758
Magenta	BBT5000M-745	BBT5000M-755	BBT5000M-759
Yellow	BBT5000Y-746	BBT5000Y-756	BBT5000Y-780

## Чорнило Універсальне №5 BARVA для Brother



Brother DCP-J100/J105/110C/115C/116C/117C/120C/J125/130C/J132W/135C/140C/J140W/145C/150C/ J152W/153C/157C/163C/165C/167C/J172W/185C/195C/197C/310CN/315CN/J315W/330C/340CW/350C/3 53C/357C/365CN/375CW/377CW/383C/385C/387C/390CN/395CN/J515N/J515W/535CN/540CN/560C N/J552DW/J572DW/585CW/595CN/J715N/J715W/750CW/J752DW/770CW/J772DW/J774DW/J785D W/J1050DW/J1100DW/J1140DW/J1200W/J1200WE/J1800DW/4020C/J4110DW/6690CW: MFC-J200/210C/215C/J220/230C/235C/240C/J245/250C/255CW/257CW/260C/J265W/290C/295CN/ 297C/410CN/J410/J415W/425CN/J430W/440CN/465CN/J470DW/J480DW/490CN/490CW/J491DW/ 495CN/J497DW/J525W/J562DW/580/590/J615N/J615W/620CN/J625DW/640CW/J650DW/660CN/6 65CW/670CD/675CD/680CN/685CW/695CD/J700D/J725DW/735CD/790CW/795CW/J800D/J805D/ J825DW/J835DW/845CW/J850DN/J855DN/J870DW/885CW/890/J890DW/J895DW/J925DW/930C DN/935CDN/J950DN/J985DW/990CW/J1010DW/J1300DW/J2310/J2320/J2330DW/J2340DW/J2510/ J2730DW/3220C/3240C/3320CN/3340C/3360C/3420C/J3520/J3530DW/J3540DW/J3720/3820CN/J3 930DW/J3940DW/J4120DW/J4335DW/J4340DW/J4340DWE/J4410DW/J4420DW/J4510DW/J4540 DW/J4610DW/J4620DW/J4625DW/J4710DW/4820C/5100J/5200J/J5320DW/J53330DW/J5335DW/J5 340DW/J5345DW/5440CN/5460CN/5490CN/J5620DW/J5625DW/J5720DW/J5730DW/J5740DW/5 840CN/5860CN/5890CN/5895CW/J5910DW/J5930DW/J5945DW/J5955DW/6490CN/6490CW/J651 0DW/J6520DW/J6530DW/J6540DW/J6710DW/J6720DW/6890CN/6890CW/6890CDW/J6910DW/J 6920DW/J6930DW/J6935DW/J6940DW/J6945DW/J6947DW/J6955DW/J6957DW/J6959DW: INTELLIFAX-1355/1360/1460/1560/1815C/1820C/1835C/1840C/1860C/1920CN/1940CN/1960C/2240C/2 480C/2580C; HL-J6000DW/J6100DW



**Black** Водорозчинне Brother LC11BK, LC16BK, LC31BK, LC37BK, LC38BK, LC39BK, LC51BK, LC57BK, LC61BK, LC65BK, LC67BK, LC103BK, LC107BK, LC121BK, LC123BK, LC127BK, LC133BK, LC137BK, LC223BK, LC227BK, LC529BK, LC535BK, LC539BK, LC563BK, LC565BK, LC567BK, LC569BK, LC600BK, LC700BK, LC800BK, LC900BK, LC960BK, LC970BK, LC975BK, LC980BK, LC985BK, LC990BK, LC1000BK, LC1100BK, LC1240BK, LC1280BK



Cyan

Brother LC11C, LC16C, LC31C, LC37C, LC38C, LC39C, LC51C, LC57C, LC61C, LC65C, LC67C, LC103C, LC107C, LC121C, LC123C, LC125C, LC223C, LC133C, LC225C, LC525C, LC535C, LC539C, LC563C, LC565C, Водорозчинне LC567C, LC600C, LC700C, LC800C, LC900C, LC960C, LC970C, LC975C, LC980C, LC985C, LC990C, LC1000C, LC1100C, LC1240C, LC1280C



Magenta

Brother LC11M, LC16M, LC31M, LC37M, LC38M, LC39M, LC51M, LC57M, LC61M, LC65M, LC67M, LC103M, LC107M, LC121M, LC123M, LC125M, LC133M, LC223M, LC225M, LC525M, LC535M, LC539M, LC563M, Водорозчинне LC565M, LC567M, LC600M, LC700M, LC800M, LC900M, LC960M, LC970M, LC975M, LC980M, LC985M, LC990M, LC1000M, LC1100M, LC1240M, LC1280M



Yellow Водорозчинне

Brother LC11Y, LC16Y, LC31Y, LC37Y, LC38Y, LC39Y, LC51Y, LC57Y, LC61Y, LC65Y, LC67Y, LC103Y, LC107Y, LC121Y, LC123Y, LC125Y, LC133Y, LC223Y, LC225Y, LC525Y, LC535Y, LC539Y, LC563Y, LC565Y, LC567Y, LC600Y, LC700Y, LC800Y, LC900Y, LC960Y, LC970Y, LC975Y, LC980Y, LC985Y, LC990Y, LC1000Y, LC1100Y, LC1240Y, LC1280Y

	90 г	180 г	1л
Black	BU5-479	BU5-490	BU5-611
Cyan	BU5-480	BU5-491	BU5-612
Magenta	BU5-481	BU5-492	BU5-613
Yellow	BU5-482	BU5-493	BU5-614
BK/C/M/Y	BU5-090-MP		