


Чорнило BTD60BK BARVA для Brother



Brother DCP-T220, T225, T300, T310, T420W, T425W, T426W, T500W, T510W, T520W, T525W, T700W, T710W, T720W, T820W; MFC-T800W, MFC-T810W, MFC-T910DW, MFC-T920DW, MFC-T4500W, HL-T4000DW



Black
Водорозчинне

Brother BTD60BK, BT6000BK

100 мл

1 л

Black

BBTD60-743

BBTD60-757


БК/С/М/У

BBTD60-100-MP

Чорнило BT5000C/ М/ У BARVA для Brother



Brother DCP-T220, T225, T300, T310, T420W, T425W, T426W, T500W, T510W, T520W, T525W, T700W, T710W, T720W, T820W; MFC-T800W, MFC-T810W, MFC-T910DW, MFC-T920DW, MFC-T4500W, HL-T4000DW




Cyan
Водорозчинне

Brother BT5000C



Magenta
Водорозчинне

Brother BT5000M



Yellow
Водорозчинне

Brother BT5000Y

100 мл

1 л

Cyan

BBT5000C-744

BBT5000C-758

Magenta

BBT5000M-745

BBT5000M-759

Yellow


BBT5000Y-746

BBT5000Y-780

Чорнило Універсальне №5 BARVA для Brother




Brother DCP-J100/ J105/ 110C/ 115C/ 116C/ 117C/ 120C/ J125/ 130C/ J132W/ 135C/ 140C/ J140W/ 145C/ 150C/ J152W/ 153C/ 157C/ 163C/ 165C/ 167C/ J172W/ 185C/ 195C/ 197C/ 310CN/ 315CN/ J315W/ 330C/ 340CW/ 350C/ 353C/ 357C/ 365CN/ 375CW/ 377CW/ 383C/ 385C/ 387C/ 390CN/ 395CN/ J515N/ J515W/ 535CN/ 540CN/ 560CN/ J552DW/ J572DW/ 585CW/ 595CN/ J715N/ J715W/ 750CW/ J752DW/ 770CW/ J772DW/ J774DW/ J785DW/ J1050DW/ J1100DW/ J1140DW/ J1200W/ J1200WE/ J1800DW/ 4020C/ J4110DW/ 6690CW/ MFC-J200/ 210C/ 215C/ J220/ 230C/ 235C/ 240C/ J245/ 250C/ 255CW/ 257CW/ 260C/ J265W/ 290C/ 295CN/ 297C/ 410CN/ J410/ J415W/ 425CN/ J430W/ 440CN/ 465CN/ J470DW/ J480DW/ 490CN/ 490CW/ J491DW/ 495CN/ J497DW/ J525W/ J562DW/ 580/ 590/ J615N/ J615W/ 620CN/ J625DW/ 640CW/ J650DW/ 660CN/ 665CW/ 670CD/ 675CD/ 680CN/ 685CW/ 695CD/ J700D/ J725DW/ 735CD/ 790CW/ 795CW/ J800D/ J805D/ J825DW/ J835DW/ 845CW/ J850DN/ J855DN/ J870DW/ 885CW/ 890/ J890DW/ J895DW/ J925DW/ 930CDN/ 935CDN/ J950DN/ J985DW/ 990CW/ J1010DW/ J1300DW/ J2310/ J2320/ J2330DW/ J2340DW/ J2510/ J2730DW/ 3220C/ 3240C/ 3320CN/ 3340C/ 3360C/ 3420C/ 33520/ J3530DW/ J3540DW/ J3720/ 3820CN/ J3930DW/ J3940DW/ J4120DW/ J4335DW/ J4340DW/ J4340DWE/ J4410DW/ J4420DW/ J4510DW/ J4540DW/ J4610DW/ J4620DW/ J4625DW/ J4710DW/ 4820C/ 5100J/ 5200J/ J5320DW/ J5330DW/ J5335DW/ J5340DW/ J5345DW/ 5440CN/ 5460CN/ 5490CN/ J5620DW/ J5625DW/ J5720DW/ J5730DW/ J5740DW/ 5840CN/ 5860CN/ 5890CN/ 5895CW/ J5910DW/ J5930DW/ J5945DW/ J5955DW/ 6490CN/ 6490CW/ J6510DW/ J6520DW/ J6530DW/ J6540DW/ J6710DW/ J6720DW/ 6890CN/ 6890CW/ 6890CDW/ J6910DW/ J6920DW/ J6930DW/ J6935DW/ J6940DW/ J6945DW/ J6947DW/ J6955DW/ J6957DW/ J6959DW/ INTELLIFAX-1355/ 1360/ 1460/ 1560/ 1815C/ 1820C/ 1835C/ 1840C/ 1860C/ 1920CN/ 1940CN/ 1960C/ 2240C/ 2480C/ 2580C/ HL-J6000DW/ J6100DW




Black
Водорозчинне

Brother LC11BK, LC16BK, LC22UBK, LC31BK, LC37BK, LC38BK, LC39BK, LC51BK, LC57BK, LC61BK, LC65BK, LC67BK, LC103BK, LC107BK, LC121BK, LC123BK, LC127BK, LC129BK, LC133BK, LC137BK, LC223BK, LC227BK, LC229BK, LC421BK, LC422BK, LC424BK, LC426BK, LC427BK, LC462BK, LC529BK, LC535BK, LC539BK, LC563BK, LC565BK, LC567BK, LC569BK, LC600BK, LC700BK, LC800BK, LC900BK, LC960BK, LC970BK, LC975BK, LC980BK, LC985BK, LC990BK, LC1000BK, LC1100BK, LC1240BK, LC1240BK, LC1280BK, LC3211BK, LC3213BK, LC3217BK, LC3219BK, LC3235BK, LC3237BK, LC3239BK, LC3617BK, LC3619BK




Цяно
Водорозчинне

Brother LC11C, LC16C, LC22UC, LC31C, LC37C, LC38C, LC39C, LC51C, LC57C, LC61C, LC65C, LC67C, LC103C, LC107C, LC121C, LC123C, LC125C, LC223C, LC133C, LC225C, LC421C, LC422C, LC424C, LC426C, LC427C, LC462C, LC525C, LC535C, LC539C, LC563C, LC565C, LC567C, LC600C, LC700C, LC800C, LC900C, LC960C, LC970C, LC975C, LC980C, LC985C, LC990C, LC1000C, LC1100C, LC1220C, LC1240C, LC1280C, LC3211C, LC3213C, LC3217C, LC3219C, LC3235C, LC3237C, LC3239C, LC3617C, LC3619C



Magenta
Водорозчинне

Brother LC11M, LC16M, LC22UM, LC31M, LC37M, LC38M, LC39M, LC51M, LC57M, LC61M, LC65M, LC67M, LC103M, LC107M, LC121M, LC123M, LC125M, LC133M, LC223M, LC225M, LC421M, LC422M, LC424M, LC426M, LC427M, LC462M, LC525M, LC535M, LC539M, LC563M, LC565M, LC567M, LC600M, LC700M, LC800M, LC900M, LC960M, LC970M, LC975M, LC980M, LC985M, LC990M, LC1000M, LC1100M, LC1220M, LC1240M, LC1280M, LC3211M, LC3213M, LC3217M, LC3219M, LC3235M, LC3237M, LC3239M, LC3617M, LC3619M



Yellow
Водорозчинне

Brother LC11Y, LC16Y, LC22UY, LC31Y, LC37Y, LC38Y, LC39Y, LC51Y, LC57Y, LC61Y, LC65Y, LC67Y, LC103Y, LC107Y, LC121Y, LC123Y, LC125Y, LC133Y, LC223Y, LC225Y, LC421Y, LC422Y, LC424Y, LC426Y, LC427Y, LC462Y, LC525Y, LC535Y, LC539Y, LC563Y, LC565Y, LC567Y, LC600Y, LC700Y, LC800Y, LC900Y, LC960Y, LC970Y, LC975Y, LC980Y, LC985Y, LC990Y, LC1000Y, LC1100Y, LC1220Y, LC1240Y, LC1280Y, LC3211Y, LC3213Y, LC3217Y, LC3219Y, LC3235Y, LC3237Y, LC3239Y, LC3617Y, LC3619Y

	100 мл	1 л
Black	BU5-479e	BU5-611
Cyan	BU5-480e	BU5-612
Magenta	BU5-481e	BU5-613
Yellow	BU5-482e	BU5-614
BK/C/M/Y	BU5-100-MP	—